

2003-2007 DODGE 5.9L CUMMINS
PLUG-N-PLAY MODULE

USER MANUAL

Disclaimer

- By installing this product onto your vehicle, you assume all risk and liability associated with its use.
- GDP Tuning, LLC. is not responsible for misuse of its products. By installing this product, you release GDP Tuning, LLC. of any and all liability associated with its use.
- The purchaser and end user releases, indemnities, discharges and holds harmless GDP Tuning, LLC. from any and all claims, damages, causes of action, injuries, or expenses resulting from or relating to the use or installation of this product that is in violation of the terms and conditions on this page, the product disclaimer, and/or the product installation instructions. GDP Tuning, LLC. will not be liable for any direct, indirect, consequential, exemplary, punitive, statutory, or incidental damages or fines caused by the use or installation of this product.

Caution

Never work on a hot vehicle. Serious injury in the form of burns can result if the vehicle has been in use. Allow vehicle to cool prior to installation. Always wear eye protection when working on or under any vehicle.

2003-2007 DODGE 5.9L CUMMINS PLUG-N-PLAY MODULE

GDP631004



- A. Plug-N-Play Module
- B. Harness

Notice:

Make sure to disconnect the negative side battery terminal before beginning your install. Failure to do so may cause CEL's and lack of performance.

Step 1

Find a proper location for mounting the module. We recommend the Fuse and Relay Center on the driver's side of the engine compartment in front of the battery. Use the supplied zip ties to fasten the module to the fuse box.



Step 2

Locate the MAP Sensor just beside the Valve cover on the driver's side of the engine. It has a blue weather tight seal. Disconnect the plug and connect ours inline with the supplied connectors.



Step 3

Locate the Fuel Pressure Sensor just in front of the MAP Sensor. Disconnect the plug and connect our supplied connectors in-line.



Step 4

Route the switch wire through the firewall to the module. We recommend utilizing an existing grommet in the firewall and running the wire through there. Make sure not to cut any wires if you need to make a new hole in the firewall.

Step 5

Now you need to decide where you want to mount your adjustable switch. If you do not want to drill your dash, we recommend mounting the switch using a GDP switch bracket.

Step 6

Re-connect the battery terminals